
Host Device (10)
UE #1
UE #2
UE #3
UE #4
UE #5
User Manager
14
16
18
Portable Device (12)
Current User Environment
20
Software
22

Figure 1


User Manager
16
No
Log In ?
24
Yes
Transmit UE to Portable Device
26
No
UE ?
28
Yes
Overwrite Revised UE
30
End

Figure 2


Browser
22
Request UE
31
UE from Host ?
32
No
Yes
34
Store UE
New Data ?
36
Yes
38
Store
No
40
Power off ?
Yes
44
Transmit UE to HOSE
End of Session ?
43
Yes
No
No
Time Out ?
Yes
42
Power Down
46
Transmit UE to Host
45
End

Figure 3


Processor
50
10
52
54
Bridge
System Memory
56
62
64
16
I/F
58
Bridge
HDD
14
Display
60
66
71
SIO
70
Modem
68
BIOS
Internet
I/F
72
18
12
I/F
74
76
78
22
Processor
Flash

Figure 4



Figure 5